

PN-215 Camera & Speaker Phone

CAMERA

- oIntegrated Camera with adjustable Flash
- oCamera Resolutions: 480x640, 240x320, 120x 60 Pixels
- oCamera Self-Portrait Capability with Flip Closed
- oSelf Timer: 3, 5 or 10 seconds
- oPhoto Effects: Sepia tone, B&W, Negative

MOBILE MEDIA

- oMobile Web 2.0
- oGet It Now® Capable
- oMobile Instant Messaging (IM)
- oPicture Messaging Service (MMS)
- oTwo-Way TXT Messaging Service (SMS)

DATA & TEXT

- oPersonal Organizer: Calendar with Scheduler, Alarm Clock, Notepad
- oTools: World Clock, Calculator, Stop Watch
- oAddress Book with 500 Contacts
- oSpeed Dialing (22 Entries)

VOICE/AUDIO

- oFull-Duplex Speakerphone
- oVoice Commands
- oVoice Memo Recorder
- o64-Chord Polyphonic Sound Support
- o15 Unique Default Ringtones or Download More
- oVibrate and Silent Modes

GENERAL

- oHandset Insurance: Yes
- oHearing Aid Compatibility = M4
- oEnglish/Spanish User Interface
- oDual Display; B/W sub LCD, internal color display
- oUp to 11 Lines of Text on Internal Display

SPECIFICATIONS

- o1.9 GHz CDMA PCS | 800 MHz CDMA/ (1X Digital Only)
- oDimensions: 3.45" (H) x 1.92" (W) x .98" (D)
- oWeight: 3.53 ounces
- oBattery: 1,000 mA AH Li-Ion
- oUsage Time: Up to 200 Minutes (Digital)
- oStandby Time: Up to 190 Hours (Digital)
- oSAR: Head 1.35, Body- .73

The Wireless Devices team introduces the PN-215 to the product line up!

Mobile IM and Email Capabilities

Adjustable Self timer for Pictures

Speakerphone

The PN-215 has arrived. From its Integrated Camera with Embedded Flash, to Picture Messaging and Voice Activated Dialing, this mobile phone gives you what you want at the price you want. Features, capabilities, endless mobility. The PN-215...just what you've been looking for.



Product Codes

DYMAX/UPC	Mock-Up Unit	FRU
PN-215 / 185742000218	PN215MOK	FRUPN215

Each PN-215 is packaged with:

- Standard Lilon Battery (1000mAh)
- AC Travel Charger
- User Guide
- Quick Reference Guide
- Welcome CD

****Holster and or case sold separately**

Confidential and proprietary material for authorized Verizon Wireless personnel only. Use, disclosure or distribution of this material is not permitted to any unauthorized persons or third parties except by written agreement.

PN-215 Accessories

Vehicle Power Charger

PANVPC-1



Travel Charger- In Box

PANTVL-1



Standard LiIon Battery (1000mAh)-In Box

PAN215BAT



Extended LiIon Battery (1800mAh)

PAN215BATX



Direct Fulfillment

Leather Case

PAN215CAS



Swivel Holster

PAN215HOL



Direct Fulf

Replacement Antenna

PAN215ANT



Direct Fulfillme

Launch packet accessories support the initial launch of this device. Accessories and part #'s may change throughout the course of the handset life. Always refer to the accessory section of the Equipment Guide to view most updated accessories listing. Click on accessory link found on the Equipment Guide

Helpful Hints

How to Send a Text Message

1. Press **Left Soft Key** for **Message** and select **New MSG (1), OK**.
2. Press **Left Soft Key** for **Add** to enter a recipient from the **Contacts, Group** or **Recent Calls** menu or use the keypad to enter a new e-mail address or phone number and press **OK, press DONE**. Up to ten recipients can be added.
3. Scroll down and enter the message (up to 160 characters) using the keypad and press **OK** for **SEND**.

OTA Instructions

1. Perform the usual billing system activation procedure.
2. Power up the phone and enter the Star Code, *228 + [send] on the handset
3. The following audio message will be heard:
"Welcome to Verizon Wireless' Over the Air programming. This call is airtime free. Press '1' to program your phone. Press '2' to update your roaming capabilities."

Note: Programming will take up to 2 minutes. Should the programming exceed 45 seconds, the following audio message will be repeated at 25-second intervals: "Please continue to hold. Your phone is being programmed."

You will hear an audio message once the phone has been successfully programmed.

How to View the Software, PRL, ERI and Browser Version

1. From the SETTINGS & TOOLS menu, select System (5)
2. Select Device Info (4)
3. Select SW Version (2)

IP Address Programming

1. Press "##BROWSER" or "##2769737" + END key
2. 7 items display on the screen
3. Press 1 for Primary Server
4. Press 2 for Secondary Server
5. Press 3 for Gateway Port Number
6. Press 4 for User Name
7. Press 5 for Password
8. Press 6 for Homepage
9. Press 7 for Service Load

Manually Programming the PN-215

1. Press "##20022002" + END key
2. Press "1" key to "Set NAM"
3. Press "000000" and press "OK"
4. Press "2" key for NAM 1
5. Press "1" key for "Mini Setup" and press "OK"
6. Press "1" and enter the Phone Number (MDN)
7. Press "OK" and press "2" key
8. Enter the "NAM1 Home SID" and press "OK"
9. Press "3" and enter the "Phone Number (MIN)"
10. Press "OK"
11. Press END key. "NAM SETUP COMPLETED" will display. Phone will turn off & then on.

Features/Advantages/Operation of the PN-215

Features	Advantage	Operation
Taking a Photo	Capture photos in any of three different resolutions (480x640, 240x320, 120x 60 Pixels) and share them with friends and family.	<ol style="list-style-type: none">1. Press the CAMERA key (located above the END key) to enter Camera Mode2. Point the camera lens at your subject and use the display screen to frame the picture3. Press OK to take the picture4. press LEFT SOFT key to save the picture,5. To go back to idle mode without saving the picture, press RIGHT SOFT key
Speakerphone	Talk on the go with your hands free. Easily switch between handset and speakerphone modes during a call.	<ol style="list-style-type: none">1. To activate/deactivate the speakerphone in idle, answering, or calling modes, press the SPEAKER key (located above the SEND key)2. The phone Speakerphone turns off when you end a call.
Mobile Web 2.0	Access the web, check news, weather, sports scores and more.	<ol style="list-style-type: none">1. Press Navigation Key up to access the web browser.2. Once the web browser is launched, you will see the Home Page.3. You can end a browser session by pressing END at any time.

PN-215

Antenna

Headset Jack

Camera Key

External LCD

Volume Key

Camera Flash

Camera Lens

Earpiece

Color Screen

Soft Keys

Navigation Key

Camera Key

END/Power Key

Send Key

Speakerphone Key

Microphone

