

## Main Menu *(To access, press the MENU key)*

1 : Calls	1 : Outgoing 2 : Incoming 3 : Missed 4 : Erase History 5 : Air Time	5 : Voice Tools	1 : Voice Memo 2 : Voice Answer
2 : Phone Book	1 : Find 2 : Add New Entry 3 : Group Setting 4 : My Phone # 5 : Memory 6 : Call Forward	6 : Sounds	1 : Ringer Volume 2 : Ringer Type 3 : Alerts 4 : Key tone 5 : Room Ringer 6 : Power On/Off 7 : Escalating
3 : Messages	1 : New MSG 2 : Voice 3 : Inbox 4 : Outbox 5 : Filled MSG 6 : WAP ALERTS 7 : Erase MSG 8 : MSG Setting	7 : Display	1 : Menu Style 2 : Wallpaper 3 : Backlight 4 : Banner 5 : Dual Clock 6 : Service LED 7 : Contrast 8 : Auto Highen 9 : Power Saving
4 : Planner	1 : Today 2 : Scheduler 3 : Task List 4 : Memo Pad 5 : Alarm 6 : Calculator 7 : World Time 8 : Countdown 9 : Set Time	8 : Games	1 : Fun Bowling 2 : Honey Ball 3 : Go Hamster
		9 : Setup	1 : Auto Answer 2 : Call Answer 3 : Auto Key Lock 4 : Auto Retry 5 : Select NAM 6 : Set System 7 : DataFax 8 : Version 9 : Security

## BASIC OPERATIONS

Make a call	Phone number +	Save a Number	Enter Number + <b>OK</b> + <b>OK</b> + ▶ / ▶ to select Label + <b>OK</b> + Enter Name + <b>OK</b> + ▶ / ▶ to select Entry/Home/Work/Mobile /Pager/Fax/No label/Speed dial/ E-mail/URL/Group/Name Ringer/Birthday/Secret/Image) + ▶ / ▶ to change the settings or <b>MENU</b> to enter information + <b>OK</b> + <b>OK</b>
End a call		Speed dialing	Enter Memory Location of the number you want, holding the last digit to automatically dial.
Receive a call		Phonebook Search	Press ▶ + ▶ / ▶ + ▶ / ▶ + <b>OK</b> or
Adjust the key beep volume	(in Standby mode)	Launch the web browser	Press and hold
Adjust the speaker volume	(during a conversation)		
Redial the last call	twice		
Switch to Silent mode	Press and hold #		