

Getting to Know Your Phone

Camera/Camcorder

Music Controls

Headset Jack

Volume Up/Down

Voice Command/
Memo Key

Charging Port

Web*

Left
Soft Key

Picture &
Video*

Calendar*

Send Key

Clear &
Back Key

Voicemail Key

Vibrate
Mode Key

Right
Soft Key

OK Key

Get It Now*

Camera/
Video Key

Power/
End Key

Speakerphone
Key

microSD™
Port

*Customizable.

Getting Music

Walkin', talkin', rockin'. Transform your wireless phone into a portable music player, then expand your collection with the Verizon Wireless music catalog.



V CAST Music

1. Press **right** on the Navigation Key, select **Music & Tones (1)**, then **V CAST Music (1)** to download new music.
2. Choose from over 1,500,000 songs! Downloaded songs are stored in **My Music**.

Sync Music from PC to Phone

1. Connect your phone to your PC with an optional USB cable*.
2. Press **right** on the Navigation Key, select **Music & Tones (1)**, then **Sync Music (6)** to sync music from PC to phone. USB cable and Windows Media Player 10 (or higher) are required.

**Sold separately*



Playing Music

The VX8350 doesn't miss a beat with its built-in music player. You can store tons of music on an optional microSD card* and even listen to them in stereo sound through a Bluetooth headset!


Flip Open

1. Press **right** on the Navigation Key, select **Music & Tones (1)**.
2. Select **My Music (4)**, choose a category, then press **OK** to play.
3. Use the side **Volume Keys**  to adjust volume when a song is playing.
4. Press the **End Key** to exit the music player.

Flip Closed

1. Press and *hold*  Key to play/pause music.
2. Press  or  to go to previous/next songs.

**Sold separately*




Note: To turn on Music Only Mode (RF off except Bluetooth), press **right** on the Navigation Key, select **Music & Tones (1)**, press the **Left Soft Key for Mode**, select **On** and press **OK**.

Bluetooth® Pairing

Enjoy hands-free entertainment and communication in the car, office, or at home with Bluetooth accessories, like a Bluetooth stereo headset for listening to music. Get wire-free convenience up to 30 feet away.

1. Set your Bluetooth accessory into pairing mode*.
2. Press **OK**, select **Settings & Tools**.
3. Select **Bluetooth Menu (3)**, then **Add New Device (1)**.
4. If Bluetooth is set to off, you will be prompted to turn power on. Select **Yes** and press **OK**.
5. Press **OK**, and the phone will now search for the accessory. Once found, highlight it and press **OK** to pair.
6. Enter the passcode (typically "0000" - 4 zeroes) and press **OK***.
7. Press **OK** to connect with the device.



**Refer to the user manual of your Bluetooth accessory to activate pairing mode and for the passcode. If the accessory supports the headset/hands-free profile, your phone will automatically pair for you without having to input the passcode.*



Note: Bluetooth accessories sold separately.

Sending Contacts via Bluetooth®

1. Press the **Right Soft Key** for **Contacts**.
2. Highlight the contact you want to send via Bluetooth, and press the **Right Soft Key** for **Options**.
3. Select **Send Name Card (9)**, then **Via Bluetooth (4)**.
4. Scroll and press **OK** to mark the contact(s) you want to send, and press the **Left Soft Key** when done.
5. Select a Bluetooth device that supports this feature, and press **OK** to send.
6. If Bluetooth is off, select **Yes** and press **OK**.



Taking a Picture/Recording a Video

Shooting photos on-the-fly has never been easier than with the 1.3 megapixel camera. Or capture all the action live and share it all instantly with Picture/Video Messaging.

1. To activate camera mode: With the flip open, press the side **Camera/Video Key** .
2. To activate video mode: With the flip open, press and *hold*  for 2 seconds.
3. Press **left** or **right** on the Navigation Key to zoom. Press **up** or **down** to adjust brightness. Press the **Right Soft Key** to adjust camera/video options.
4. Press  to take a photo or record a video. Press  to stop recording.
5. Press the **Left Soft Key** to save or  to send.

Note: To take a self-portrait, close phone and press and *hold* . Then press  take the picture.



Optional Accessories

Accessories for convenience and fashion are available at www.VerizonWireless.com.



Bluetooth Headset



Bluetooth Stereo Headset



Bluetooth Stereo Speakers



Swivel Holster



Portable Stereo Speakers



Music Essentials Kit

©2007 LG Electronics, Inc. All rights reserved. All other trademarks are property of their respective owners. All phone images are simulated. The Bluetooth® trademark and logos are owned by the Bluetooth SIG, Inc. and any use of such marks by LG Electronics is under license.